



Favored End

Short List

These items must be completed to avoid injury to the passengers or damage to the Favored End!

Done?

- 1 Check the engine oil level before starting & every two hours of operation.
- 2 Check to see that a stream of water is exiting engine when running.
- 3 Check the life preservers and unlock the locker when underway.
- 4 Check the fuel tank level.
- 5 Exit and enter the dock slowly. Clearance is tight and the boat does not change direction rapidly.
- 6 Turn off all lights, radio and other battery powered devices when not in use.
- 7 Pump out and rinse the Porta Potty after use.
- 8 When leaving make sure the battery switch is in the off position.
- 9 Lock up & clean up when leaving.
- 10 Advise the Boatswain if there are any problems on the Favored End.

Thanks for your help and I hope you had an enjoyable day!



Favored End

Departing

"Favored End" is located at V-4 In Aqualand Marina. Please review all the instructions for Departing, Underway and Return of the boat **BEFORE** starting up the boat or departing from the dock. This is for your safety and to help maintain "Favored End" in good condition.

Thanks for your help and have an enjoyable day!

Done?

- ___ 1 The combination for the forward port locker can be obtained from the Race Committee chairperson or the Boatswain. The engine key and the other locker key is on a hook at the rear of the locker. You will need this key to open all the other lockers.
- ___ 2 Check to determine that the life preservers are in good condition and that there is one for each passenger. (There should be 10 in the locker) **The lock must be unlocked before departing & while underway!**
- ___ 3 Locate the first aid kit, flares, emergency horns (in cooler), lighting switches (on console) and registration (briefcase).
- ___ 4 Check the fuel level in the tank. The fuel gauge does not work so you must visually check the tank. Note the level.
- ___ 5 Turn battery selector switch to "All". This utilizes the power of both batteries to start the engine.
- ___ 6 Using the Trim Switch on the throttle station, lower the motor to the vertical position and straighten it out .
- ___ 7 Visually check the oil level by viewing the clear plastic gauge on the front of the motor or carefully removing the cap on top of the outboard. If required fill the reservoir using the oil in the starboard side compartment. Please use the funnel.
- ___ 8 Raise the Fast Idle lever (front lever on station) to the full up position. This is the start position.
- ___ 9 Turn the ignition key to the right to start the engine. You may have to crank it several times before it starts. Pushing the key in primes the engine with gas.
- ___ 10 After the engine starts, move the Fast Idle lever to a slow idle and allow the engine to warm up for 1 or 2 minutes. Prior to getting underway move the Fast Idle lever to the horizontal position.
- ___ 11 Check that a steady stream of water is exiting the aft starboard side of the engine above water level. This is the cooling water discharge. If no water stream is visible **STOP THE ENGINE** to avoid overheating and damaging the engine.
- ___ 12 When ready to depart, the bow and spring lines should be taken off the cleats on the boat and left on the dock. The two aft lines should be disconnected from the dock cleat and left on the boat.
- ___ 13 If additional dock lines are needed at the fuel dock there are additional lines on the port rail and the starboard forward locker. Do not use the anchor lines or cut any other lines!
- ___ 14 Take care when backing out Favored End. The clearance to the dock and slipmate is tight.

Fuel tank level on arrival: _____

Oil reservoir level on arrival: _____

Operator's Name: _____

Date: _____



Favored End

Underway

- 1 When in open water, boat speed can be increased by adjusting the angle of the engine slightly using the Trim Switch. Pushing the top of the switch will raise the engine slightly raising the bow slightly. The boat will move more easily through the water. Take care not to raise the engine more than 15 degrees from the transom mount.
- 2 If additional dock lines are needed at the fuel dock there are additional lines on the port rail and the starboard forward locker. Do not use the anchor lines or cut any other lines!
- 3 Fuel the boat at Aqualand. Please check the oil reservoir anytime that you fuel up. Please submit the fuel receipt to the BFSC Purser for reimbursement.
- 4 When the boat is anchored out on the lake, turn the battery switch to the Battery #1 position. This will keep Battery #2 in reserve to restart the engine. Do not put the battery switch in the Off position when the engine is operating as this will burn up the alternator.
- 5 If you are out on the lake and are operating the light, radio or other boat battery powered devices, it is strongly recommended that you start the engine periodically (once an hour for 15 minutes) to assure that it will restart and to charge the batteries. Having an engine that will not start really ruins the day!
- 6 Please check the oil level on the outboard every two hours of operating time. Stop and refill if needed.
- 7 The Porta Potty is located in the aft locker. Toilet paper is located in the adjacent supply locker. The curtain can be lowered from the roof for privacy. If the Porta Potty is used you are responsible to pump it out at the Aqualand gas dock and rinse it when you return.
- 8 To use the air horn, open the valve on top of the tank one turn to the left. The regulator does not need to be adjusted. The regulator valve does not shut tight so after blowing the horn turn off the tank valve to save air. There is an Ecohorn and emergency horns in the white

Operator's Name: _____

Date: _____



Favored End

Returning

Done?

- ___ 1 Take care when docking Favored End. The clearance to the dock and slipmate is tight. Come in slow!
- ___ 2 Assure all the dock lines are secure.
- ___ 3 Shut off the engine and return the key to the forward port locker hook.
- ___ 4 Raise the engine all the way up out of the water.
- ___ 5 Turn off all lights, radio and other battery powered devices.
- ___ 6 Turn the Battery Selector switch to the "Off" position.
- ___ 7 Close the air horn air cylinder valve by turning it clockwise all the way.
- ___ 8 Empty out and rinse the Porta Potty.
- ___ 9 Check the engine oil level. Fill if needed. Record oil level.

- ___ 10 Check the fuel tank level. Record tank level. **If it is less than 1/4 tank please call the boatswain (404-259-6420) so we can advise the next person to use the boat.**
- ___ 11 Clean up the dock and anchor lines.
- ___ 12 Perform a general clean up of the boat.
- ___ 13 Please record any problems on the Trip Report and send it to the Boatswain in the envelope along with this record. This is the best way for me to know of items that need to be fixed.

Oil reservoir level
on leaving: _____

Fuel tank level on
leaving: _____

Thanks for your help and I hope you had an enjoyable day!

Operator's Name: _____

Date: _____

